

S1151 Crankshaft Sprocket

READ BEFORE INSTALLATION

Attention: The Cloyes S1151 crankshaft sprocket requires the installation of the included friction washers. The Cloyes supplied S1151 requires the installation of new friction washers against the front and rear face of the sprocket during assembly. These washers are supplied with this sprocket. If the original sprocket utilized friction washers, you must ensure they are removed with the old sprocket and not stuck to the crankshaft or balancer. **Failure to install the friction washers with the Cloyes sprocket, or installing new washers with old washers still in place, will cause sprocket misalignment and possible timing system wear/failure.**

S1151 Engrane de Cigüeñal

LÉA ANTES DE INSTALAR

Atención: El engrane de cigüeñal Cloyes S1151 debe ser instalado con las arandelas de fricción que se incluyen. El engrane S1151 que Cloyes provee requiere de la instalación de nuevas arandelas de fricción sobre las caras frontal y traseras del engrane durante el montaje. Estas arandelas son proveídas junto con este engrane. Si el engrane original utilizó arandelas de fricción, asegúrese de removerlas junto con el engrane usado y no colocarlas en el engrane de cigüeñal o engrane de balance. **Equivocarse al instalar las arandelas de fricción con el engrane Cloyes, o instalar arandelas nuevas con usadas, provocará una desalineación del engrane y posibles fallas o desgaste en la distribución.**